

## Adding Preventive Maintenance Requirements (without PM workbooks)

1 → Get CVe Data

2 → Scheduled Maintenance (PM)

3 → Add PM

4 → ConfigurePM dialog

5 → Add button in ConfigurePM dialog

Title	Target PM Interval	PM Performed	PM Due	First PM
Standard PM	2000	103000	105000	503
Hot Runner PM	100000	98705	198705	98705
Major PM	15000	98705	113705	14500

**Edit PM**  
 ➔ Click on row.  
 ▲ Edit Configure PM window.

For complete OnDemand software instructions, please refer to the User Guide.  
 For technical assistance please email: [helpdesk@asttech.com](mailto:helpdesk@asttech.com).