

## Configure in Press PM

CVe ON DEMAND

CVe Device ID  
OPZ0088

Status  
Custom Data Download Complete... Beginning readback verification...

2

Tool Info | Target Data | **Scheduled Maintenance (PM)** | Settings | Support | Reports

Maintenance Required Total Cycles 18

Title	Target PM Inte...	PM Performed	PM due	Init PM CP
Standard PM	2000	103000	105000	503
Hot Runner PM	100000	98705	198705	98705
Major PM	15000	98705	113705	14500

3

1 **Get CVe Data** **Add PM** **In Press PM**

**PROGRESSIVE**  
C O M P O N E N T S

© 2020. Progressive Components. All rights reserved.

ConfigureInPressPM

4 Target Interval (cycles) 500

Initial PM (cycles) 500

5 OK Cancel

In Press PM Update Notification

✓

i In Press PM Init and Interval values updated successfully

OK

For complete OnDemand software instructions, please refer to the User Guide.  
For technical assistance please email: [SystemMonitoring@procomps.com](mailto:SystemMonitoring@procomps.com).